



Karen Christians  
Western Avenue Studios, #561  
122 Western Avenue  
Lowell, MA 01851  
[Karen@karenchristians.com](mailto:Karen@karenchristians.com)  
[www.karenchristians.com](http://www.karenchristians.com)  
781 367 4992

### Care and Feeding for a Karen Christians ErgoLast Titanium Pick

Congratulations on investing in a quality handmade tool.

- 1) To best use this pick, gently heat the tip with your torch and plunge it into flux. Repeat this three times, allowing for a sturdy flux layer for your solder to float and roll onto your heated pik. Do not allow the end to glow red. Flux will not adhere correctly.
- 2) Cleaning. Your pic can be cleaned in pickle, citric acid, or vinegar and salt solutions. Titanium is inert in pickle and will not transfer any ionic plating to your work.
- 3) If you find any residue after a hot bath, simply clean with Scotchbrite until the tip is clean.
- 4) The pad at the end is designed to hold a pesky bezel or wire down to your base.
- 5) The swirl inhibits rolling and makes it easy to fetch.
- 6) Light in your hand and no heat transfer make this a long-lasting and durable tool. Ergo Last Picks last a lifetime.

Any of my tools are 100% refundable if you are unsatisfied within 15 days of purchase.

Show me what you got! I would love to hear from you about how your pick is working out.

Best,

Karen