

Operating Instructions for the Pepetools Dust Collector

Item No. 331.00 / 331.220 / 332.00 / 332.220

The left side of the rocker switch operates the light fixtures and suction fans. The right side rocker switch operates the polishing motor. The drawers on the front of the unit are held tightly in place with the screw knobs on the left and right sides of the drawers. These drawers contain the dust filters and are designed for easy access and changeability. It is important to change the filters on a regular basis. **To change filters, first turn the machine off.** Unscrew the locking knobs on the left and right side of the drawer. Pull the drawer out, remove the old filter and replace with new ones. Once the filters are replaced, slide the drawer back into position and tighten knobs. Be certain to use Pepetools high density filters.

Warning: For Professional Use Only

Eye protection must be worn when operating this equipment. Keep loose clothing, hair, gloves and other dangling objects away from the turning spindles and buffs or wheels attached to the spindles. Entanglements of such objects can result in serious injury.